RECOMMENDED FOR ADDITIONAL RAIL SUPPORT. INSTALL ST100 STUB SUPPORTS

1. Locate center of rail, and drill 3/16" hole in bottom of rail.
2. Hand tighten stub support in place.
3. Adjust support higher or lower to match your rail height.
4. Mark location of support leg holes and install with lag screws or masonry anchors.